



Exploded		
View No.	Qt	Contents
5.	1	Gasket, Top (PJ34, PJ36)
	1	Gasket, Top (PJ38)
10.	1	Clip, Jet Needle
14.	1	Air Adjustment Screw
15.	1	Spring
18.	1	Baffler Plate
21.	1	Float Valve
22.	1	Clip, Float Valve
23.	1	Float Pin
25.	1	O-Ring, Float Bowl
28.	4	Screw, Float Bowl
29.	1	Plug Screw O-Ring